


# ASSEMBLY INSTRUCTIONS

REFER TO THE PACKING LIST FOR A COMPLETE LIST OF COMPONENTS AND PART NUMBERS

FOLLOW THE STEPS TO ASSEMBLE AND ERECT YOUR POWER PRO BASKETBALL TOWER.



| FOR PART | QTY | FASTENERS / BOLT LIST              |
|----------|-----|------------------------------------|
| B-E      | 1   | M10 X 170 MM BOLT AND NYLOC NUTS   |
|          | 2   | M10 NYLON WASHERS (TO BE GLUED)    |
|          | 2   | M10 WASHERS                        |
| B-D      | 1   | M10 X 170 MM BOLT AND NYLOC NUTS   |
|          | 2   | M10 NYLON WASHERS (TO BE GLUED)    |
|          | 2   | M10 WASHERS                        |
| J-D      | 2   | M10 X 50 MM BOLT AND NYLOC NUT     |
|          | 2   | M10 NYLON WASHERS (TO BE GLUED)    |
|          | 4   | M10 WASHERS                        |
| J-E      | 2   | M10 X 50 MM BOLT AND NYLOC NUT     |
|          | 2   | M10 NYLON WASHERS (TO BE GLUED)    |
|          | 4   | M10 WASHERS                        |
| D-H      | 1   | M12 X 170 MM BOLT AND NYLOC NUT    |
|          | 2   | M12 WASHERS                        |
| B-H      | 1   | M10 X 83 MM BOLT AND NYLOC NUT     |
|          | 2   | M10 WASHERS                        |
| J-G-F    | 4   | M10 X 75 MM BOLT AND NYLOC NUT     |
|          | 8   | M10 WASHERS                        |
| C        | 1   | M12 X 25 MM BOLT                   |
| B        | 1   | M5 X 40 MM BOLT & NYLOC (ATTACHED) |
| -        | -   | -                                  |

- 1) CONCRETE THE GROUND SLEEVE IN POSITION, USE A SPIRIT LEVEL AND LEAVE TO CURE FOR 4 DAYS. (NOTE: TOP OF GROUND SLEEVE SHOULD SIT 30 MM ABOVE PLAYING SURFACE).
- 2) PLACE THE BASE POLE IN THE SLEEVE, ALIGN THE POLE AND TIGHTEN THE SLEEVE BOLT.
- 3) SLIDE THE NYLON WASHER OVER THE BOTTOM OF THE ROTATING POLE AND INSERT INTO THE BASE POLE.
- 4) BOLT THE TWO EXTENSION ARMS TO THE ROTATING POLE (NOTE THE WINDER HOLE IN THE TOP EXTENSION ARM).
- 5) BOLT THE ADJUSTABLE WINDER TO THE EXTENSION ARM BRACKET AND TOP EXTENSION ARM.
- 6) BOLT THE 4 BRACKETS TO THE BACKBOARD FRAME. THEN BOLT THE BACKBOARD FRAME AND BRACKETS TO THE EXTENSION ARMS.
- 7) BOLT THE BASKETBALL RING TO THE BACKBOARD FRAME.

NOTE:  
DO NOT OVER TIGHTEN NYLOC NUTS. THEY SHOULD BE TIGHTENED TO REDUCE PLAY BUT STILL ALLOW THE PIVOTING PARTS TO MOVE WITHOUT TENSION.

|  |
|--|
| TITLE:<br><b>POWER PRO BASKETBALL TOWER</b>  |
| DRAWING NUMBER:<br>POWER PRO ASSEMBLY 1 OF 3   |
|  |
| <b>Oz Ring Pty Ltd</b><br>Trading as:<br><b>Play Hard Sports Equipment</b><br>ABN 79 066 094 559<br>24 Ern Harley Drive<br>Burleigh Heads Qld 4220<br>Phone: (07) 5593 4494<br>Fax: (07) 5593 4338<br>Website: <a href="http://www.playhardsports.com.au">www.playhardsports.com.au</a><br>Email: <a href="mailto:email@playhardsports.com.au">email@playhardsports.com.au</a> |